# FIRST MILE VEHICLE SERVICE CONTRACTS®



# **FOUR COVERAGE LEVELS\***

\*Coverage level availability may be limited based on the age and mileage of your vehicle. New vehicle protection plans are available that provide additional protection beyond your vehicle's manufacturer's warranty ("Wrap Protection").

# POWERTRAIN **GOLD PLUS** PLATINUM





Reimbursement up to \$35 per day for up to 10 days.\*

**TOWING COVERAGE** 

Reimbursement of up to \$75 in towing charges per covered mechanical breakdown.\*

TRAVEL COVERAGE

If you're more than 100 miles from home when you break down, we will reimburse up to \$75 per day, up to \$375 per occurrence, for food and lodging.

**FLUID COVERAGE** 

Replacement of necessary fluids, oils, greases, lubricants and approved air conditioner gases that must be replaced in conjunction with a covered repair,

**IMPROVED RESALE** 


Each plan is fully transferable, making your car more appealing to potential buyers.

**OVER 5,000 SERVICE CENTERS IN THE U.S.** 

Receive service at greater than 5,000 authorized service centers and repair facilities.

# **AVERAGE REPLACEMENT COSTS**

(PARTS, LABOR AND ANCILLARY COSTS)



In case of a breakdown, you must contact the selling dealer. If you have moved or are traveling out of town, call the Administrator toll-free: 1-800-870-6856.

To start a claim via the mobile app, please scan the applicable QR code.

**ANDROID** 





<sup>\*</sup>Only available in the event of a covered breakdown.

### **POWERTRAIN** PLAN

#### **ENGINE**

Engine block and cylinder heads and all internally lubricated parts including pistons, piston rings, pins and cylinder sleeves

Crankshaft, pulley, main bearings, caps and bolts

Connecting rods, rod bearings, caps and bolts

Camshaft(s), camshaft bearings, button and plugs

Timing gears and timing chain or belt

Rocker arms, rocker arm pivots, shafts and bushings

Intake and exhaust valves, springs, guides, adjusters, retainers and

TRANSMISSION

Transmission/transaxle

including ring and pinion

case and all internally

Oil pump, cover, gears,

housing and vanes

Torque converter

Governor, gear and

Parking gear and pawl

Valve body(s)

Throttle valve

Valve pack

cover

Roll pins

Sprockets

Sprags

Chain

Springs

Solenoids

Rands

Stator and shaft

Pressure switches

Pressure regulator valve

Automatic transmission/

transaxle clutch, drums.

pistons and steel plates

lubricated parts

Pushrods and lifters Intake manifold

**Thermostat** 

and screen

nuts and bolts

Turbocharger/

and wastegate

Seals and gaskets

Servos and rings

Blockers

Bearings

Bushings

Adjusters

nuts and bolts

Yoke

Control rings

Extension housing

Speedometer drive

Accumulators and rings

All internal fasteners,

Shift cover and forks

Separate bell housing

internal parts contained

within the transfer case

Transfer case and all

Seals and gaskets

Oil pump, cover, gears,

pressure relieve valve

Rotor housing, rotors,

shims and silent shaft

All internal fasteners,

supercharger assembly

Planetary and sun gears

Synchronizer hubs and

including boost valve

Exhaust manifolds Oil pan, valve, timing and side covers Balance shaft

Water numn Fuel pump

Thermostat housing Water pump pulley

control arms, shafts and Powertrain Plan plus the following: bushings Struts, housing and

FRONT SUSPENSION

Ball joints and bushings

Kingpin and bushings

Stabilizer bar, links and

Torsion bar, mounts and

Track bar, links and

Mirror motor switch

Neutral safety switch

Glove box light switch

Courtesy light switch

Air control solenoid

Air regulator valve

Electronic ignition

Engine distributor

including shaft, gear,

bushings and modules

Throttle position sensor

Vehicle speed sensor

M.A.P. sensor Knock

pressure sensor

sensor and barometric

Electronic instrument

I.A.C. motor

panel module

lanition coil

module

Cooling fan relay

Brake light switch

bushings

bushings

hushings

Upper and lower

ELECTRICAL

Alternator housing

and all internal parts

rectifier bridge, diodes,

including bearings,

bushings, brushes,

field coil and rotor

Voltage regulator

Starter motor housing

brushes, field windings,

and all internal parts

Front and rear wiper

Power window motor

Window regulators

and speed control

motor, transmission and

including bushings,

starter drive and

bracket

solenoid

linkage

Alternator mounting

cartridge Engine mounts Spindle/steering knuckle

Harmonic balancer and spindle support Flex plate/flywheel and Wheel bearings

#### TRANSMISSION

**GOLD** PLAN

Includes everything covered under the

Oil pan

ENGINE

Detent cable Kickdown link Tvi/throttle cable Vacuum modulator Transmission mounts

ring gear

#### DRIVE AXLE

Constant velocity joints Slip joint

Front wheel drive axles/ halfshafts and wheel bearings

Couplings Flex disc Prop shafts

**U-joints** 

Center support bearings

#### **■** STEERING

Steering gear housing and internal parts including control rings, valves, pinion shaft, pitman shaft, worm shaft and gear, sector shaft, bearings, adjusters

Rack and pinion housing and internal parts Supports and shafts including control valve, rack bellows, mounts. rack shaft and yoke, spool valve, bearings

BRAKES

Master cylinder

and fittings

Compensator/

Metering valve

dust boot

boots

Vacuum or hydraulic

Hydraulic lines, hoses

Brake pedal apply pin

proportioning valve

Calipers, piston, seal and

Wheel cylinders, cups,

seals, spring and dust

brake booster assembly

Power steering pump and internal parts

including housing, reservoir, shaft and vanes

Power steering pump mounting brackets

Power seat motor Steering column multi-Tie rods, idler and function switch and pitman arms, center/ individual switches for drag link, coupling and turn signal, headlamp, dimmer, wiper, washer

Cooler lines

Backing plate

Brake adjusters

and pedal pivot

including control

processor/module,

pump, dump valve,

Seals and gaskets

wheel speed sensors,

solenoids, accumulator,

and pressure differential

Parking brake cable

ABS component parts

Brake pedal, pedal lever

Seals and gaskets

## **GOLD PLUS PLAN**

#### Includes everything covered under the Gold Plan

#### COOLING

Radiator, mounting brackets and coolant recovery tank

Fan clutch, fan blades and motor

Fan shroud Heater core

Transmission cooler

processor, throttle body

assembly, cutoff valve,

fuel rail, fuel distributor,

start valve, fuel injection

valve, fuel accumulator

trigger contacts, cold

Tank door latch

#### FUEL

Fuel lines Fuel pressure regulator Level sending unit

Fuel injectors and seals

Injection pump

ESC systems

Fuel injection control Tank filler neck and a-ring components including

Tank

#### mixture control

AIR CONDITIONING

Idler pulley and bearings

Air conditioning/heater blower motor

#### STEERING

Steering wheel tilt and telescoping mechanism

#### **▶** FRONT SUSPENSION

Coil and leaf springs, seats and bushings, leaf spring shackles

Electronic level control components including pump, accumulator, lines and bags

#### REAR SUSPENSION

Upper and lower control arms, shafts and **bushings** 

Upper and lower ball ioints Struts, housing and

cartridge Wheel bearings

Spindle/steering knuckle and spindle support

Coil and leaf springs, seats and bushings, leaf spring shackles

Track bars, links and bushings

Electronic level control components including pump, accumulator, lines

Stabilizer bar, links and bushinas

#### ELECTRICAL

Cruise control module, servo, cables and

Instrument cluster including speedometer odometer, tachometer and all gauges, warning

Burglar alarm or electronic entry systems including remote entry receiver, sender and module

Door lock actuators

Mirror motor

Power window switch, power lock switch

Rear window defogger

Horn and relay

Convertible top motor

Sunroof motor Power antenna motor

Electrical headlamp motor

Power trunk/hatch release motor, switch and solenoid

Power sliding door motor and switch

Electronic control modules including body control module, electronic control unit powertrain control module, transmission control module

Electronic throttle control module

Crank angle sensor

Camshaft position sensor

Throttle position motor Fuel pulse dampener

Wide open throttle switch

Thermo time switch

Fuel pump relay Automatic temperature control sensor

Ride height sensor and

Oxygen (o2) sensor

Mass air flow sensor

Manifold differential pressure sensor

Coolant temperature sensor

OEM radio/graphic equalizer/cassette tape player/compact disc

## **PLATINUM** PLAN

The most comprehensive mechanical coverage available for your new or pre-owned vehicle

Includes everything covered under the Gold Plus Plan plus the following:

Compact disc player (3) Radio assembly, speaker

system and antenna

Anti-theft system (3)

Navigation system (3)

Rain sensing wiper system

Steering wheel and integrated controls

Heated windshield MacPherson struts

Cruise control system

**Evaporative emissions** TV, VCR and DVD systems Liftgate motor Night vision system

relavs

...AND MUCH MORE!

3) Factory Installed

Most on-board

Back up camera

Back up sensors

computers, sensors and

#### WHAT IS NOT COVERED (EXCLUSIONS)

Remote keyless entry

Electronic level control

and leaf springs

elements

Torsion bars, coil springs,

Heated and cooled seat

1. The maintenance services and parts described under Maintenance Requirements as shown in the Vehicle Service Contract or the Manufacturer's Maintenance Schedule for your

2. Other normal maintenance services and parts, including engine tune-up (includes spark plugs, glow plugs, ignition wires, distributor cap and rotor), carburetor, batteries (including but not limited to: hybrid batteries), filters, lubricants or fluids, all hoses and belts (not specifically listed), brake pads and shoes, brake rotors and drums, suspension alignment, constant velocity boots, tires, wheels, suspension airbags, exhaust system, and catalytic converter.

3. Glass, glass framework and fastening adhesives, sealed beam head lamps, light bulbs, lenses, trim, moldings, bright metal, upholstery, paint, sheet metal, bumpers, alignment of body parts, door panels, body panels, structural framework, and removable hardtop assemblies

4. Aftermarket accessories or equipment, components and systems not installed by the manufacturer.

(4) Additional exclusions apply; see the Vehicle Service Contract for details.

NOTE: Coverage under Powertrain, Gold, and Gold Plus Coverage Plans is limited to only those parts and components described in this brochure. Parts not listed are not covered.

**IN FLORIDA - OBLIGOR & ADMINISTRATOR: AUTOMOTIVE WARRANTY SERVICES** OF FLORIDA, INC. Florida Company Code #60023 175 W. Jackson Blvd. Chicago, IL 60604

> **OTHER STATES - ADMINISTRATOR:** TOTAL WARRANTY SERVICES PO Box 810187, Boca Raton, FL 33481, 800.870.6856, Fax: 561.537.7215, www.firstmilewarranty.com

The product being offered is a service contract and is separate and distinct from any product or service warranty which may be provided by the manufacturer, importer, or seller.

FOR FLORIDA RESIDENTS - NOTICE TO CONSUMER Administrator may use replacement parts in covered repairs that may include new, remanufactured, used or non-original equipment manufactured parts.

#### FOR IDAHO RESIDENTS

This is an advertisement or offer to sell a motor Vehicle Service Contract. The sender of this communication is not the motor vehicle manufacturer of your vehicle or a licensed Idaho Automobile dealer nor affiliated with a motor vehicle manufacturer or Idaho Automobile dealer.

#### DRIVE AXLE

Differential/axle housing(s) and all internal lubricated parts including the axle flange Ring and pinion gear/

carrier assembly Spider gears and bearings

TWS-VSCL (02/23)

(Standard transmission clutch assemblies and all

component parts are not covered.)

Retainers

Positraction clutches. plates and springs

Pins

Seals and gaskets

#### AIR CONDITIONING

Condenser Compressor

Evaporator

Orifice/expansion valve Accumulator

Receiver drier Automatic temperature control programmer

Clutch assembly including coil, disc and pullev

Cutoff switch Serpentine belt tensioner, bearing and

Control cables

pulley

Seals and gaskets

Compressor mounting brackets